



VERTICAL PANEL BRACES INSIDE ARENA

REVERSE PANEL SO THAT VERTICAL PANEL BRACES ARE OUTSIDE OF ARENA (PIN SIDE WILL BE CONNECTING TO STRIPPING CHUTE)

NOTICE: MAKE SURE VERTICAL PANEL BRACES ARE OUTSIDE OF ALLEY AND PIN SIDE IS TOWARD STRIPPING CHUTE

150' X 250' TEAM ROPER PLUS

(10'-0" Panels)

NOTE: WHEN SETTING UP THE ARENA IT IS BEST TO LEAVE THIS END (STRIPPING CHUTE) FOR LAST SO THAT YOU CAN ADJUST PANELS AS NEEDED.