

TEXAS SWINE SALOON

INSTRUCTIONS

PARTS INCLUDED:

- 1 SALOON DOOR PANEL
- 1 REG. PANEL WITH CHAIN LINK (TOP CENTER)
- 2 REG. PANELS
- 8 NUT/BOLT SETS
- 1 SPRING
- 1 DOOR RELEASE MECHANISM
- 1 CABLE

WHEN CARRYING THE PANELS IT IS EASIEST TO GRAB THEM FROM INSIDE THE CURVE.



ONE PANEL AT A TIME SET UP AND MAKE YOUR CIRCLE, MAKE SURE THE PANEL WITH THE CHAIN LINK (TOP CENTER) IS DIRECTLY ACROSS FROM THE DOOR PANEL.



ONCE ALL FOUR PIECES ARE STANDING IN THE CORRECT POSITION BEGIN TO BOLT THE DOOR PANEL TO THE TWO ON EITHER SIDE FIRST STARTING WITH THE BOTTOM BOLT AND THEN THE TOP BOLT.



AFTER ALL PANELS ARE SECURELY BOLTED TOGETHER INSTALL YOUR SPRING INTO THE TWO CHAIN LINKS ONE ON EACH DOOR ACROSS FROM EACH OTHER.



THEN INSERT YOUR DOOR RELEASE MECHANISM (SCISSOR MECHANISM) INTO THE PIPE WELDED ON EACH DOOR WITH THE HINGE END TOWARD THE CENTER OF THE TRAP.



THE CABLE WILL REST OVER THE VERTICAL BAR NEAR THE HINGE OF THE DOOR RELEASE MECHANISM.



SETTING THE TRAP

REACH INSIDE THE DOOR AREA AND SPREAD COMPLETELY APART UNTIL IT LOCKS INTO PLACE.



PLACE THE LOOP OF THE CABLE AROUND THE VERTICAL BAR NEAR THE HINGE ON THE DOOR RELEASE MECHANISM. RUN THE OTHER END OF THE CABLE ACROSS AND DOWN THRU THE CHAIN LINK WELDED ON THE PANEL ACROSS FROM THE DOOR LEAVING ABOUT 2" OF SLACK IN CABLE.



BRING CABLE BACK DOWN TO THE GROUND ABOUT A FOOT OFF OF THE SIDE AND MID WAY OF THE TRAP. DRIVE A STAKE TO ANCHOR THE END LOOP TO THE GROUND.



NOTE: WHEN THE TRAP IS TRIGGERED THE END OF THE CABLE THAT WAS ON THE DOOR RELEASE MECHANISM WILL FALL OFF TO PREVENT DAMAGE TO THE TRAP.