


***RED RIVER ARENAS.com***

***“Spend Less, Get More!”***

***800-343-1026***



NOTE: WHEN SETTING UP THE ARENA IT IS BEST TO LEAVE THIS END (STRIPPING CHUTE) FOR LAST SO THAT YOU CAN ADJUST PANELS AS NEEDED.

This drawing is the property of RedRiverArenas.com. RedRiverArenas does not authorize the reproduction or conveyance of any information contained herein without prior written permission.

### DIMENSIONS

REDRIVERARENAS.COM

PHONE : 1-325-625-1900


TUBE-S16-00-A

# 140 X 240 W/RETURN EXCAVATION AREA

MINIMUM EXCAVATION AREA IS 150'-0" BY 254'-0"



- 1 Start by staking out the Arena Area (140'-0" by 240'-0") to use as a guideline for panels.

NOTE: IF EXCAVATION EXCEEDS THE GIVEN DIMENSIONS OWNER WILL NEED TO COMPENSATE ACCORDINGLY




# 140 X 240 w/ RETURN ROPING CHUTE LOCATION

② Position the BACK Corner **A** of the Roping Chute at the dimension shown below:



# PANEL TO CHUTE CONNECTION



**ROPING CHUTE LEFT SIDE**

**PANEL**

**STANDING BEHIND THE CHUTE  
PANEL TO LEFT SIDE CHUTE CONNECTION**

This drawing is the property of RedRiverArenas.com  
RedRiverArenas does not authorize the reproduction or  
conveyance of any information contained herein  
without prior written permission.


**PANEL TO CHUTE LEFT**

REDRIVERARENAS.COM

PHONE : 1-325-625-1900

TUBE-S16-00-A

# PANEL TO CHUTE CONNECTION



**PANEL**

**ROPING CHUTE RIGHT SIDE**

**STANDING BEHIND THE CHUTE  
PANEL TO RIGHT SIDE CHUTE CONNECTION**

This drawing is the property of RedRiverArenas.com  
RedRiverArenas does not authorize the reproduction or  
conveyance of any information contained herein  
without prior written permission.

**PANEL TO CHUTE RIGHT**

REDRIVERARENAS.COM


PHONE : 1-325-625-1900

TUBE-S16-00-A

# PANEL TO PANEL CONNECTION (CHAIN CONNECTION)

## PANEL CHAIN CONNECTION

1. USING THE MARK(S) YOU MAKE WITH THE STRING. ALIGN AND CONNECT ONE PANEL AT A TIME.
2. WRAP CHAIN AROUND PANEL LEG AND ATTACH TO CHAIN KEEPER.
3. PANL SHOULD NOW BE CONNECTED. YOU CAN ADJUST ONE PANEL 90° FOR BALANCE.



## PANEL TO PANEL CONNECTION WITH CHAINS